



NOTES:

1. ALL JOINTS SHALL BE SOLVENT WELD JOINTS.
2. PRESSURE TEST PRESSURE LATERAL BEFORE CONNECTING TO WYE.
3. ARRANGE TEST SO THAT FINAL CONNECTION DOES NOT DISTURB PRESSURE TEST, PRESSURE LINE COMPONENTS OR FITTINGS.
4. AFTER CONNECTION OF PRESSURE LINE AT WYE, TEST FULL ASSEMBLY TO 5 PSI.



**Snyder Basin Water
Reclamation District**

**SANITARY SEWER PRESSURE LINE
TO GRAVITY LINE CONNECTION**

**STANDARD DETAIL
LAT-06**

Revision Date: 2/22/16